

3P Tuscan Butt

Art No. 9000700K



6. Fitting the 3P Filter Collector

Push the green spiral hose on to the hose-tail and secure with jubilee clip provided. Fit the other end on to the smallest Filter Collector outlet.



Locking the Lid

Rotate lid to lock and ensure child-safe.

3P Tuscan Butt

Art No. 9000700K



3P Tuscan Butt 275 Litre

Installation Instructions

We recommend the optional 3P Filter Collector with Universal Link Kit to fill this water butt



You may also use other UK diverters. Refer to the instructions for your diverter.

3P Tuscan Butt

Art No. 9000700K



Setting Up

Site the water butt on a firm level surface, adjacent to your down-pipe.

Refer to your down-pipe diverter instructions.

You can choose whether to fit the tap supplied, or not.

Fitting the tap (Optional)



1. Locate Tap-point (Optional)

You do not have to install a tap. The Butt can be used by plunging a watering can into the water. Find the tap point; a flat circular area on the side of the water-butt, around 300mm from the bottom.



2. Hole cutter selection - 28mm

Select the 28mm flat bit from the set. This is the smallest available in the set. Please double check before drilling.



3. Drilling

Offer the drill to the centre of the tap point, mark if necessary. Carefully proceed to drill the hole with the 28mm holesaw.



4. Attach tap and back-nut

Push the tap through the hole and screw the back-nut on tightly, this will form a water tight seal.

3P Tuscan Butt

Art No. 9000700K

Attaching an optional 3P Filter Collector Universal



1. Marking Out

Measure down 70mm from the lip of the water butt. This should be at a point equidistant from the two bayonet lid locking positions.

This position is ideal for all connections at 32mm (DN32, 1 1/4") or less.



2.1 Hole Cutter Selection - 32mm

To fill the water butt with the recommended '3P Filter Collector Universal' select the 32mm flat bit from the set provided. This is the second smallest available in the set.

2.2 Other Diverters & Connectors

Refer to your diverter's instructions for the correct sized hole to form. You may be able to use the hole saws supplied by 3P. Check first.



3. Drilling

Offer the drill to the marked point, proceed to drill the hole at 32mm (or at your selected holes size for your connection set.) Check and re-check you are going to drill the correct size of hole for the connection set that you are using.



4. Attaching a Back-Nut & Hose Tail

A back nut and rubber seal can be fitted as shown. Hold the back-nut and rubber seal in position and screw in the hose-tail



5. Hosetail in Position

This picture shows a 1" BSP thread - 32mm hosetail in position (within a 32mm drilled hole).